

DATA SHEET



DIGIPIESA 

FHK G1/4" thermal PVDF

Part number 937-14XX/AE192

General Description

The FHK Flowmeter with thermal probe is a general-purpose device; its working range can be individually defined according to its nozzle size. It is employed for measuring, regulating or metering and guarantees most precise measurement of fluid quantities. In addition, a pulse generator integrated into the flowmeter guarantees a practically unlimited useful life.

Specific applications: Inlet and outlet on the same side, compact design, great working range, depending on the nozzle diameter. **Temperature sensor integrated.**

Approvals / Standards

EN 50081-1:92, EN 50082-1:97,
EN 61000-3-2:00, EN 61000-3-3:95,
IEC 61000-6-3:96, IEC 61000-6-1:96,
IEC 61000-3-2-00, IEC 61000-3-3:94 + A1:01



Material:

Housing:	PVDF glass ball reinforced 30%
Bearing pin:	Inox 1.4571
Hull:	Inox 1.4571
Nozzle:	PTFE
O-ring:	EPDM
Turbine:	PVDF 2 Magnets 4 Magnets on request
Magnets:	Keramik Sr Fe O (not in contact with the medium)
Screw:	Inox A2 PT-screws (Phillips cross recessed)


Technical data:

Flow rate:	0.041 - 6 l/min depending on the nozzle diameter
Measuring accuracy:	+/- 2.0%
Repetition:	< +/- 0.5%
Temperature range:	-10°C to +100°C 14°F to 212°F
Pressure range:	20 bar at 20°C 290 psi / 68°F
Mounting position:	Horizontal recommended
Nozzle size:	Ø 1.0, 1.2, 1.5, 2.0, 2.5, 3.3 mm

Electrical connection ratings:

Power supply:	4.5–24 VDC
Consumption:	5 mA to max. 13 mA
Signal connection:	Open collector NPN
Signal voltage:	0 V GND
Signal load:	max. 20 mA
Leakage current:	max. 10 µA
Thermal probe:	NTC 10kΩ 60mW R/T8016 B25/100 3988K
Connections:	Cable 4 x 0.14²mm 650mm length
Signal:	Square-wave output
Duty Cycle:	50% / ± 5%

Dimensions in mm:



RESISTANCE


Special regulations which must be complied with by the flowmeter manufacturer apply to each country, e.g. CE, NSF, FDA and SK. The various media flowing through the flowmeter differ from application to application. You are advised to enquire with the medium manufacturer as to whether the entire installation and the flowmeter are resistant to the medium itself (see Material)!

ELECTRONIC

DIGMESA electronic circuitry is always designed for operation with DIGMESA flowmeters. Please note the following if connecting to other electronic circuitry:



- The flowmeter does not supply an output voltage but switches the signal terminal to 0 V ground (actuated) or leaves it open (non-actuated)
- There must be a pull-up resistor between power supply + and signal depending on electronic circuitry!

Interface Connection: Examples Open Collector



DIGITECH

Measurement Curve FHK PVDF bearing pin Inox 1.00 mm



Medium: Water / max. Pressure: 3.3 bar

Nozzle size	Pulses/litre	g/pulse	min. flow rate in litres/min at Linear start	max. flow rate in litres/min	Pressure loss
Ø 1.00 mm	2277	0.4392	0.0419	0.5899	1.00
Ø 1.20 mm	1834	0.5452	0.0343	0.8014	1.00
Ø 1.50 mm	1447	0.6912	0.0523	1.2731	1.00
Ø 2.00 mm	1010	0.9903	0.0692	2.3482	1.00
Ø 2.50 mm	739	1.3533	0.0664	3.7142	1.00
Ø 3.30 mm	555	1.8015	0.7173	6.0997	1.00

The values specified must be considered as approximate values.



The number of pulses per litre may differ depending on medium and installation.

We recommend to calibrate the number of pulses per litre in line with the complete installation.

MEASUREMENT TIPS

- Ensure that there is no fast-pulsatory movement of the media
- Ensure that there are no reverse pressure surges
- Ensure that there is no air in the system
- Note the mounting position of the flowmeter
- Min/max flow should be in the linear range of the selected flowmeter
- Clean the system at appropriate intervals
- Avoid electrical current peaks
- Incorrect cabling of power supply +, signal and ground will destroy the flowmeter
- Do not mechanically load electrical contacts
- Avoid moisture on the electrical contacts
- Avoid stray pick-up via the cable (Do not lay cables in parallel with high current loads)

Measurement Curve FHK PVDF bearing pin Inox 1.20 mm



Medium: Water / max. Pressure: 3.3 bar

Nozzle size	Pulses/litre	g/pulse	min. flow rate in litres/min at Linear start	max. flow rate in litres/min	Pressure loss
Ø 1.00 mm	2277	0.4392	0.0419	0.5899	1.00
Ø 1.20 mm	1834	0.5452	0.0343	0.8014	1.00
Ø 1.50 mm	1447	0.6912	0.0523	1.2731	1.00
Ø 2.00 mm	1010	0.9903	0.0692	2.3482	1.00
Ø 2.50 mm	739	1.3533	0.0664	3.7142	1.00
Ø 3.30 mm	555	1.8015	0.7173	6.0997	1.00

The values specified must be considered as approximate values.



The number of pulses per litre may differ depending on medium and installation.

We recommend to calibrate the number of pulses per litre in line with the complete installation.

MEASUREMENT TIPS

- Ensure that there is no fast-pulsatory movement of the media
- Ensure that there are no reverse pressure surges
- Ensure that there is no air in the system
- Note the mounting position of the flowmeter
- Min/max flow should be in the linear range of the selected flowmeter
- Clean the system at appropriate intervals
- Avoid electrical current peaks
- Incorrect cabling of power supply +, signal and ground will destroy the flowmeter
- Do not mechanically load electrical contacts
- Avoid moisture on the electrical contacts
- Avoid stray pick-up via the cable (Do not lay cables in parallel with high current loads)

Measurement Curve FHK PVDF bearing pin Inox 1.50 mm



Medium: Water / max. Pressure: 3.3 bar

Nozzle size	Pulses/litre	g/pulse	min. flow rate in litres/min at Linear start	max. flow rate in litres/min	Pressure loss
Ø 1.00 mm	2277	0.4392	0.0419	0.5899	1.00
Ø 1.20 mm	1834	0.5452	0.0343	0.8014	1.00
Ø 1.50 mm	1447	0.6912	0.0523	1.2731	1.00
Ø 2.00 mm	1010	0.9903	0.0692	2.3482	1.00
Ø 2.50 mm	739	1.3533	0.0664	3.7142	1.00
Ø 3.30 mm	555	1.8015	0.7173	6.0997	1.00

MEASUREMENT TIPS



- Ensure that there is no fast-pulsatory movement of the media
- Ensure that there are no reverse pressure surges
- Ensure that there is no air in the system
- Note the mounting position of the flowmeter
- Min/max flow should be in the linear range of the selected flowmeter
- Clean the system at appropriate intervals
- Avoid electrical current peaks
- Incorrect cabling of power supply +, signal and ground will destroy the flowmeter
- Do not mechanically load electrical contacts
- Avoid moisture on the electrical contacts
- Avoid stray pick-up via the cable (Do not lay cables in parallel with high current loads)

The values specified must be considered as approximate values.

The number of pulses per litre may differ depending on medium and installation.

We recommend to calibrate the number of pulses per litre in line with the complete installation.

Measurement Curve FHK PVDF bearing pin Inox 2.00 mm



Medium: Water / max. Pressure: 3.3 bar

Nozzle size	Pulses/litre	g/pulse	min. flow rate in litres/min at Linear start	max. flow rate in litres/min	Pressure loss
Ø 1.00 mm	2277	0.4392	0.0419	0.5899	1.00
Ø 1.20 mm	1834	0.5452	0.0343	0.8014	1.00
Ø 1.50 mm	1447	0.6912	0.0523	1.2731	1.00
Ø 2.00 mm	1010	0.9903	0.0692	2.3482	1.00
Ø 2.50 mm	739	1.3533	0.0664	3.7142	1.00
Ø 3.30 mm	555	1.8015	0.7173	6.0997	1.00

The values specified must be considered as approximate values.



The number of pulses per litre may differ depending on medium and installation.

We recommend to calibrate the number of pulses per litre in line with the complete installation.

MEASUREMENT TIPS

- Ensure that there is no fast-pulsatory movement of the media
- Ensure that there are no reverse pressure surges
- Ensure that there is no air in the system
- Note the mounting position of the flowmeter
- Min/max flow should be in the linear range of the selected flowmeter
- Clean the system at appropriate intervals
- Avoid electrical current peaks
- Incorrect cabling of power supply +, signal and ground will destroy the flowmeter
- Do not mechanically load electrical contacts
- Avoid moisture on the electrical contacts
- Avoid stray pick-up via the cable (Do not lay cables in parallel with high current loads)

Measurement Curve FHK PVDF bearing pin Inox 2.50 mm



Medium: Water / max. Pressure: 3.3 bar

Nozzle size	Pulses/litre	g/pulse	min. flow rate in litres/min at Linear start	max. flow rate in litres/min	Pressure loss
Ø 1.00 mm	2277	0.4392	0.0419	0.5899	1.00
Ø 1.20 mm	1834	0.5452	0.0343	0.8014	1.00
Ø 1.50 mm	1447	0.6912	0.0523	1.2731	1.00
Ø 2.00 mm	1010	0.9903	0.0692	2.3482	1.00
Ø 2.50 mm	739	1.3533	0.0664	3.7142	1.00
Ø 3.30 mm	555	1.8015	0.7173	6.0997	1.00

The values specified must be considered as approximate values.



The number of pulses per litre may differ depending on medium and installation.

We recommend to calibrate the number of pulses per litre in line with the complete installation.

MEASUREMENT TIPS

- Ensure that there is no fast-pulsatory movement of the media
- Ensure that there are no reverse pressure surges
- Ensure that there is no air in the system
- Note the mounting position of the flowmeter
- Min/max flow should be in the linear range of the selected flowmeter
- Clean the system at appropriate intervals
- Avoid electrical current peaks
- Incorrect cabling of power supply +, signal and ground will destroy the flowmeter
- Do not mechanically load electrical contacts
- Avoid moisture on the electrical contacts
- Avoid stray pick-up via the cable (Do not lay cables in parallel with high current loads)

Measurement Curve FHK PVDF bearing pin Inox 3.30 mm



Medium: Water / max. Pressure: 3.3 bar

Nozzle size	Pulses/litre	g/pulse	min. flow rate in litres/min at Linear start	max. flow rate in litres/min	Pressure loss
Ø 1.00 mm	2277	0.4392	0.0419	0.5899	1.00
Ø 1.20 mm	1834	0.5452	0.0343	0.8014	1.00
Ø 1.50 mm	1447	0.6912	0.0523	1.2731	1.00
Ø 2.00 mm	1010	0.9903	0.0692	2.3482	1.00
Ø 2.50 mm	739	1.3533	0.0664	3.7142	1.00
Ø 3.30 mm	555	1.8015	0.7173	6.0997	1.00

The values specified must be considered as approximate values.

The number of pulses per litre may differ depending on medium and installation.

We recommend to calibrate the number of pulses per litre in line with the complete installation.

MEASUREMENT TIPS

- Ensure that there is no fast-pulsatory movement of the media
- Ensure that there are no reverse pressure surges
- Ensure that there is no air in the system
- Note the mounting position of the flowmeter
- Min/max flow should be in the linear range of the selected flowmeter
- Clean the system at appropriate intervals
- Avoid electrical current peaks
- Incorrect cabling of power supply +, signal and ground will destroy the flowmeter
- Do not mechanically load electrical contacts
- Avoid moisture on the electrical contacts
- Avoid stray pick-up via the cable (Do not lay cables in parallel with high current loads)

